

	本機をお使いになるための準備や基礎的な知識、基本的な共通操作をまとめて	準備/基礎知識	1
	説明しています。必ずお読みください。	共通操作	2
		電話	3
	本機の代表的な機能を、章単位でまとめて説明しています。	メール	4
		インターネット	5
	お使いになりたい機能の章をお読みください。	テレビ	6
		カメラ/静止画編集	7
		メディアプレイヤー/S!アプリ	8
	木継で利用できるその他の便利がソールやサービフについて説明しています	ツール	9
	本機で利用できるその他の便利なツールやサービスについて説明しています。	ツール エンタテイメント/コミュニケーション	9
	本機で利用できるその他の便利なツールやサービスについて説明しています。 本機のセキュリティを強化する機能について説明しています。		
		エンタテイメント/コミュニケーション	10
	本機のセキュリティを強化する機能について説明しています。	エンタテイメント/コミュニケーション セキュリティ	10 11
	本機のセキュリティを強化する機能について説明しています。 本機に保存されるデータ、データの管理方法について説明しています。	エンタテイメント/コミュニケーション セキュリティ データフォルダ/メモリカード	10 11 12
	本機のセキュリティを強化する機能について説明しています。 本機に保存されるデータ、データの管理方法について説明しています。 データ通信やパソコン接続、データのバックアップについて説明しています。	エンタテイメント/コミュニケーション セキュリティ データフォルダ/メモリカード 通信/バックアップ	10 11 12 13



本書は、基本的にお買い上げ時の状態での操作方法を説明しています。 設定が変更されていたり、他の機能が動作しているときなどは、動作が異なったり、動作しないことがあります。また、本書内の画面は実際の画面表示とは 異なります。あらかじめご了承のうえ、操作の目安としてご利用ください。



本書の見かた P.iv






パラパラ めくって探す

本機でできることを見つけましょう。

各誌面の内容は説明のための サンプルです。実際の誌面と は異なります。 ページの端には機能やサービス名などを記載しています。気になる言葉を探しましょう。




●項目の開始ページでは、上の例のように大き く機能やサービス名などを記載しています。 以降のページでは小さく記載しています。 章の始まりには、扉ページが付いています。 区切りの目安にしましょう。



●章の冒頭などには、その章で説明する機能やサービスの内容をまとめた概要ページがあります。ここで全体像をつかんでください。(一部ない章もあります。)

説明ページのレイアウトはいくつかのパターンに分かれています。それぞれのパターンの意味 を覚えておけば、必要な箇所だけを読むことができます。

●基本操作パターン



機能やサービスの基本操作を 説明しているページです。章の 前半にあります。 ●応用操作パターン



機能やサービスの応用的な操作を説明しているページです。 章の後半にあります。 ●設定操作パターン



全般的な設定を説明しているページです。「**共通設定**」の章にあります。

 ◆上記パターンのほか、各機能やサービスで動作がおかしいときなどに確認する「こんなときは」が各章 末にあります。(一部ない章もあります。)

全体像が一覧できる「目次」と、章内の内容がわかる「章目次」を活用しましょう。



「目次」には、ページ端の機能やサービス名が記載されています。また、各章の扉ページに入っている「章目次」は、章内の内容が詳しく記載されています。目的に応じて使い分けてください。

用語と目的で引ける2つの「索引」で目的の 機能や用語をすばやく見つけましょう。



●本機内の用語があいうえお順に並んでいる「用 語索引」と、「閲覧する」「保存する」などの目的別 にまとめた「目的別索引」を「資料/付録」の章に 掲載しています。ご活用ください。

目的の機能や 用語を探す

いろいろな方法で、検索が行えます。

各誌面の内容は説明のための サンプルです。実際の誌面と は異なります。

メニューなどの項目の意味や操作を調べる ときは、「メニュー一覧」がおすすめです。



●「資料/付録」の章の「メニューー覧」は、本機のメニュー構造に沿って、各項目の掲載ページを記載しています。操作中に気になる項目があれば、ここから説明ページが確認できます。

画面に表示されるマークの意味を知りたいときは、「マークの見かた」をご覧ください。



「準備/基礎知識」の章にある「画面とマークの見かた」には、画面に表示されるマークの意味をまとめた「マークの見かた」の項目があります。知らないマークが表示されたときに確認しましょう。

表示やマーク の意味を探す


気になる項目や マークを調べましょう。

各誌面の内容は説明のための サンプルです。実際の誌面と は異なります。

本書の見かた



目次/付属品 P.vi



....

0

3.5

設定操作

| 本機の共通設定操作を表形式で説 | 明しています。

共通操作

表内の各操作に共通する操作を示しています。この共通操作を行ったあと、続けて表内の操作を行ってください。

こんなときは

動作がおかしいときの確認や対応 の方法などを説明しています。



2

よくある疑問や事例を記載しています。

操作にあたってのご注意

●本書は、特にことわりがない限り、本機を開いた状態(オープンポジション: で P.1-2)で、待受画面(で P.1-6)からの操作を中心に説明しています。

目次/付属品 P.vi

目次/付属品

本書の構成	i	検索	2-16	E 25.55 ± .1	
機能の探しかた	ii	ちょこっとメモ	2-17	5 インターネット	
本書の見かた	iv	電話帳登録	2-18	インターネット	
目次/付属品		電話帳利用		Yahoo!ケータイ	5-3
安全上のご注意	ix	便利な機能	2-22	PCサイトブラウザ	5-4
Safety Precautions	xxi	こんなときは	2-28	画面操作	
1 準備/基礎知識		3 電話		ブックマーク/画面メモ RSSフィード	
各部の名称	1-2	電話	3-2	便利な機能	
電池パックの充電		音声電話		こんなときは	
電源On/Off		TVコール	3-5		
画面とマークの見かた	1-7	着デコ	3-6	6 テレビ	
タッチパネル	1-12	スピードダイヤル		デジタルTV	6-2
機能呼び出し	1-14	通話情報確認		録画/再生	6-8
誤動作防止		発着信制限		録画/視聴予約	6-10
モーションコントロール	1-25	オプションサービス	3-11	タイムシフト	
マナーについて	1-27	便利な機能		便利な機能	6-12
暗証番号		こんなときは	3-21	こんなときは	6-18
その他の基礎知識		4 メール		7 カメラ/静止画編集	
ダブルナンバー		4 メール			
便利な機能		メール		カメラ	
2 共通操作		メール送信		静止画撮影	
		メール受信/確認		動画撮影	
共通操作		メール管理/利用	4-12	画像レビュー	7-12
文字サイズ		チャットフォルダ		特殊撮影	
壁紙	2-4	メールグループ	4-16	静止画編集	
 きせかえアレンジ		PCメール		静止画プリント	
音・バイブ・ライト		便利な機能		便利な機能	
文字入力		こんなときは	4-35	こんなときは	7-26
ユーザー辞書					
スマートリンク辞書	2-14				

0 47 77 45 4617	-0	ボイスレコーダー9-3	
8 メディアプレイヤー/S!アフ		バーコード読み取り9-3	12 データフォルダ/メモリカード
メディアプレイヤー	. 8-2	QRコード作成9-3	6 データフォルダ12-2
音楽再生		名刺読み取り9-3	7 メモリカード12-5
動画再生	. 8-5	文字読み取り9-3	8 便利な機能 12-7
音楽/動画管理	. 8-6	ラクラク瞬漢ルーペ9-3	9 こんなときは12-9
S!アプリ	. 8-7	便利な機能 9-4	
便利な機能	. 8-8	こんなときは9-!	:0 3 通信/バックアップ
こんなときは			
		10 エンタテイメント/コミュニケーション	赤外線通信
9 ツール		エンタテイメント10	
ツール	9-2	モバイルウィジェット	
カレンダー/予定リスト		S!速報ニュース10	
アラーム		S!情報チャンネル 10	
お目覚めTV	9-11	電子ブック10	
リラクゼーションタイム		コミュニケーション10	
電卓	9-14	S!ともだち状況10-	
マネー積算メモ	9-15	S!一斉トーク 10-1	2
おサイフケータイ®	9-16	ちかチャット10- ⁻	5 5 14 共通設定
見せかけコール		ブログツール10-	6 日時設定14-2
ストップウォッチ	9-21	便利な機能 10-	
キッチンタイマー	9-22	こんなときは10-2	5 着信設定14-5
世界時計9	9-23	11 セキュリティ	■ 音設定14-6
時報	9-24	111 セキュリティ	通信設定14-7
歩数計	9-25	セキュリティ11	2 初期化14-8
簡易方位計	9-27	使用禁止/制限11	-3
S! GPSナビ	9-28	顔認証11	.5
ドキュメントビューア	9-31	ケータイ機能制御11	-7
メモ帳		便利な機能11	-8
アスキーアート	9-33		

15 資料/付録

USIMカード	
電池パック	15-4
ソフトウェア更新	15-5
故障かな?と思ったら	
文字入力用ボタン	15-8
ポケベルコード	15-10
区点コード	15-11
お天気アイコン	15-17
仕様	15-18
メニュー一覧	15-25
索引	15-33
保証書/アフターサービス	15-41
お問い合わせ先	

付属品

■電池パック (SHBCC1)



- ●付属品/オプション品については、お問い合わせ先(で全でである)。 い合わせ先(でででする)。 ださい。
- ・充電器/イヤホンマイクは、ソフトバン クが指定したオプション品を使用してく ださい。

安全上のご注意

/!\ 汪惠

で使用の前に、この「**安全上のご注意**」をよくお読みのうえ、正しく お使いください。また、お読みになったあとは大切に保管してください。

- ●ここに示した注意事項は、お使いになる人や、他の人への危害、財産への損害を未然に防ぐための内容を記載していますので、必ずお守りください。
- ◆本製品の故障、誤動作または不具合などにより、通話などの機会を 逸したために、お客様、または第三者が受けられた損害につきましては、当社は責任を負いかねますのであらかじめで了承ください。

次の表示の区分は、表示内容を守らず、誤った使用をした場合に生じる危害や損害の程度を説明しています。内容をよく 理解したうえで本文をお読みください。

<u></u> 危険	この表示は、取り扱いを誤った場合、「死亡または重傷を負う危険が切迫して生じることが想定される」内容です。
<u></u> 警告	この表示は、取り扱いを誤った場合、「死亡 または重傷を負う可能性が想定される」内 容です。
^ ^>	この表示は、取り扱いを誤った場合、「傷害

を負う可能性が想定される場合および物的

損害のみの発生が想定される」内容です。

次の絵表示の区分は、お守りいただく内容を説明しています。 内容をよく理解したうえで本文をお読みください。



禁止(してはいけないこと)を示します。



分解してはいけないことを示します。



水がかかる場所で使用したり、水に濡らしたり してはいけないことを示します。



濡れた手で扱ってはいけないことを示します。



指示に基づく行為の強制(必ず実行していただくこと)を示します。



を抜く

電源プラグをコンセントから抜いていただくことを示します。

本機、電池パック、USIMカード、 充雷器(オプション品)、 メモリカード (オプション品) の取り扱いについて (共通)

⚠ 危険

本機に使用する電池パック・充電器 (オプション品)・卓上ホルダー(オ プション品) は、ソフトバンクが指 定したものを使用してください。



指定品以外のものを使用した場合は、雷 池パックの漏液・発熱・破裂・発火や、充 雷器の発熱・発火・故障などの原因とな ります。

分解・改造・ハンダ付けなどお客様 による修理をしないでください。



火災・けが・感雷などの事故または故障 の原因となります。また、雷池パックの 漏液・発熱・破裂・発火などの原因となり ます。

本機の改造は雷波法違反となり、罰則の 対象となります。


濡らさないでください。




水やペットの尿などの液体が入ったと きに、濡れたまま放置したり、濡れた電 池パックを充電すると、発熱・感電・火 災・けが・故障などの原因となります。 使用場所、取り扱いにご注意ください。



高温になる場所(火のそば、暖房器 具のそば、直射日光の当たる場所、炎 天下の車内など) で充電・使用・放 置しないでください。



本機に電池パックを取り付けたり、充 電器を接続する際、うまく取り付け や接続ができないときは、無理に行 わないでください。雷池パックや端 子の向きを確かめてから、取り付け や接続を行ってください。





本機・電池パック・充電器を、加熱 調理機器 (雷子レンジなど)・高圧容 器(圧力釜など)の中に入れたり、電 磁調理器(IH調理器)の上に置いた りしないでください。



雷池パックの漏液・発熱・破裂・発火や、 本機と充雷器の発熱・発煙・発火・故障な どの原因となります。



プロパンガス、ガソリンなどの引火 性ガスや粉塵の発生する場所(ガソ リンスタンドなど)では、必ず事前 に本機の電源をお切りください。 また、充雷もしないでください。



ガスに引火する恐れがあります。 ガソリンスタンド構内などでおサイフ ケータイ®対応携帯電話をご利用にな る際は、雷源を切った状態で使用してく ださい。(IC カードロックを設定されて いる場合は、ロックを解除した上で電源 をお切りください。)

落としたり、投げたりして、強い衝 撃を与えないでください。



雷池パックの漏液・発熱・破裂・発火や火 災・感雷・故障などの原因となります。

使用中、充電中、保管時に、異音・ 発煙・異臭など、今までと異なるこ とに気づいたときは、次の作業を行っ



- てください。 1.コンセントやシガーライターソケッ トから充電器を持ってプラグを抜い てください。
- 2. 本機の電源を切ってください。
- 3. やけどやけがに注意して、電池パッ クを取り外してください。

異常な状態のまま使用すると、火災や感 電などの原因となります。

充電端子や外部機器端子、メモリカー ドスロットに水やペットの尿などの 液体や導電性異物(鉛筆の芯や金属 片、金属製のネックレス、ヘアピン など) が触れないようにしてくださ い。また内部に入れないようにして ください。



ショートによる火災や故障などの原因 となります。

指示

⚠ 注意

ぐらついた台の上や傾いた所など、不 安定な場所に置かないでください。 落下して、けがや故障などの原因となり ます。バイブレータ設定中や充電中は、 特にご注意ください。





乳幼児の手の届かない場所に保管し てください。



誤って飲み込んだり、けがなどの原因と なります。



子供が使用する場合は、保護者が取 り扱い方法を教えてください。使用 中においても、指示どおりに使用し ているかをご注意ください。



けがなどの原因となります。

雷池パックの取り扱いについて

⚠ 危険

電池パックのラベルに記載されている表示によ り、電池の種類を確認した上で、ご利用・処分 をしてください。

表示	電池の種類	
Li-ion00	リチウムイオン電池	

火の中に投下しないでください。 電池パックを漏液・破裂・発火させるな どの原因となります。



釘を刺したり、ハンマーでたたいた り、踏みつけたり、強い衝撃を与え ないでください。

電池パックを漏液・発熱・破裂・発火させ るなどの原因となります。



指示

指示

電池パックの端子に、針金などの金 属類を接触させないでください。ま た、導電性異物(鉛筆の芯や金属片、 金属製のネックレス、ヘアピンなど) と一緒に電池パックを持ち運んだり 保管したりしないでください。

電池パックを漏液・発熱・破裂・発火させ るなどの原因となります。

雷池パック内部の液が眼の中に入っ たときは、こすらず、すぐにきれい な水で洗い流し、ただちに医師の診 察を受けてください。




失明などの原因となります。

⚠ 警告

雷池パック内部の液が皮膚や衣服に 付着した場合は、ただちに本機の使 用をやめ、きれいな水で洗い流して ください。

皮膚に傷害を起こすなどの原因となり ます。

所定の充電時間を超えても充電が完 了しない場合は、充電を中止してく ださい。




電池パックを漏液・発熱・破裂・発火させ るなどの原因となります。



電池パックの使用中・充電中・保管 時に、異臭・発熱・変色・変形など、 今までと異なることに気づいたとき は、やけどやけがに注意して電池パッ クを取り外し、さらに火気から遠ざ けてください。

異常な状態のまま使用すると、電池パッ クを漏液・発熱・破裂・発火させるなどの 原因となります。

ペットが電池パックに噛みつかない ようご注意ください。





⚠ 注意

不要になった電池パックは、一般の ゴミと一緒に捨てないでください。 端子にテープなどを貼り、個別回収に出 すか、最寄りの「ソフトバンクショップ | へお持ちください。



電池を分別している市町村では、その規 則に従って処理してください。

本機の取り扱いについて

⚠ 警告

自動車、バイク、自転車などの乗り物 の運転中には使用しないでください。 交通事故の原因となります。



乗り物を運転しながら携帯電話を使用 することは、法律で禁止されており、罰 則の対象となります。

運転者が使用する場合は、駐停車が禁止 されていない安全な場所に止めてから ご使用ください。

モバイルライトの発光部を人の目に 近づけて点灯発光しないでください。

視力障害の原因となります。また、目が くらんだり、驚いたりしてけがなどの事 故の原因となります。



注意事項·

当製品に使用のモバイルラ イト光源LEDは、指定されて いない調整等の操作を意図 的に行った場合、眼の安全性 を招える光量を放出する可



能性がありますので分解しないでください。修理は、 指定のサービスステーションに限定されています。



■ 干バイルライト光源I FD特件

- a) 連続発光
- b) 波長
 - 户·400-700nm
- c) 最大出力
 - 白·840 u W (内部4.8mW)


高精度な制御や微弱な信号を取り扱 う雷子機器の近くでは、本機の雷源 を切ってください。

雷子機器が誤動作するなどの影響を与 える場合があります。


※ ご注意いただきたい電子機器の例

補聴器・植込み型心臓ペースメーカ・ 植込み型除細動器・その他の医用電気 機器・火災報知器・自動ドア・その他の 白動制御機器など

本機の電波により運航の安全に支障 をきたす恐れがあるため、航空機内 では電源をお切りください。



心臓の弱い方は、着信時のバイブレー ション(振動)や着信音量の設定に 注意してください。



だちに電源を切って屋内などの安全 な場所に移動してください。 落雷や感電の原因となります。

赤外線ポートを目に向けて送信しな いでください。

目に影響を与える可能性があります。

モーションコントロール操作時は、周 りの安全を確認したうえで、本機を しっかり握り、強く振りすぎないでく ださい。

人や物に当ったり、けがなどの事故や故 障および破損の原因となります。

指示


指示

指示

指示

禁止

車両電子機器に影響を与える場合は 使用しないでください。



⚠ 注意

禁止

指示

本機の使用により、皮膚に異常が生 じた場合は、ただちに使用をやめて 医師の診察を受けてください。

本機では材料として金属などを使用し ています。お客様の体質や体調によって は、かゆみ・かぶれ・湿疹などが生じるこ とがあります。(使用材料: CT P.15-18)

本機に磁気カードなどを近づけたり、 挟んだりしないでください。

キャッシュカード・クレジットカード・ テレホンカード・フロッピーディスクな どの磁気データが消えてしまうことが あります。



ストラップなどを持って本機を振り 回さないでください。

本人や周囲の人に当ったり、ストラップ が切れたりして、けがなどの事故や故障 および触指の原因となります。



本機を長時間ご使用になる場合、特 に高温環境では熱くなることがあり ますので、ご注意ください。

長時間肌にふれたまま使用していると、 低温やけどになる恐れがあります。



指示

着信音が鳴っているときや、本機で メロディを再生しているときなどは、 スピーカーに耳を近づけないでくだ さい。



難聴になる可能性があります。

本機を開閉する際は、指やストラッ プなどを挟まないようご注意くださ L1



けがなどの事故や破損の原因となりま す。



デジタルテレビを視聴するときは、充 分明るい場所で、画面からある程度 の距離を空けてご使用ください。 視力低下につながる可能性があります。

イヤホンを使用するときは音量に気 をつけてください。



長時間使用して難聴になったり、突然大 きな音が出て耳をいためたりする原因 となります。

充電器(オプション品)の取り扱いについて

⚠ 警告

充電中は、布や布団でおおったり、包 んだりしないでください。



熱がこもって火災や故障などの原因と なります。




指定以外の雷源・雷圧で使用しない でください。



指定以外の電源・電圧で使用すると、火 災や故障などの原因となります。

- ●ACアダプタ(オプション品):AC100V~ 240V(家庭用ACコンセント専用)
- ●シガーライター充電器(オプション 品):DC12V·24V(マイナスアース車 専用)

また、海外旅行用として、市販されてい る「変圧器」は使用しないでください。火 災・感電・故障の原因となります。





感電・火災・故障の原因となります。

シガーライター充電器(オプション 品)のヒューズが切れたときは、必 ず指定のヒューズに交換してくださ い。



指定以外のヒューズを使用すると、火災 や故障の原因となります。指定のヒュー ズに関しては、シガーライター充電器の 取扱説明書でご確認ください。

万一、水やペットの尿などの液体が 入った場合は、ただちに充雷器を持っ て、コンセントやシガーライターソ ケットからプラグを抜いてください。 感雷・発煙・火災の原因となります。



雷源プラグ を抜く

プラグにほこりがついたときは、充 電器を持ってプラグをコンセントか ら抜き、乾いた布などでふき取って ください。



火災の原因となります。

シガーライター充雷器(オプション 品)は、マイナスアース重専用です。 プラスアース重には絶対に使用しな いでください。



火災などの原因となります。

充電器をコンセントに差し込むとき は、卓上ホルダーの端子および充電 器のプラグや端子に導電性異物(鉛 筆の芯や金属片、金属製のネックレ ス、ヘアピンなど) が触れないよう に注意して、確実に差し込んでくだ さい。



感雷・ショート・火災などの原因となり ます。

濡れた手で充雷器のプラグを抜き差 ししないでください。 感電や故障などの原因となります。



濡れ手禁止

雷が鳴り出したら、充電器には触れ ないでください。



感電などの原因となります。

⚠ 注意


お手入れの際は、コンヤントやシガー ライターソケットから、必ず充電器 を持ってプラグを抜いてください。 感電などの原因となります。



充電器をコンセントやシガーライター ソケットから抜くときは、コードを 引っ張らず、充電器を持ってプラグ を抜いてください。



コードを引っ張るとコードが傷つき、感 雷や火災などの原因となります。





けがや故障の原因となります。

通雷中は卓 トホルダー(オプション 品) の充電端子に長時間触れないで ください。



低温やけどになる恐れがあります。



医用電気機器近くでの取り扱いについて

ここで記載している内容は、「**医用電気機器への** 雷波の影響を防止するための携帯電話端末等の 使用に関する指針」(雷波環境協議会「平成9年 4月1) に準拠、ならびに「電波の医用機器等へ の影響に関する調査研究報告書1(平成13年3月 「社団法人雷波産業会」)の内容を参考にしたも のです。

⚠ 警告

植込み型心臓ペースメーカおよび植 込み型除細動器を装着されている場 合は、ペースメーカ等の装着部位か ら22cm以上離して携行および使用し てください。




電波により植込み型心臓ペースメーカ および植込み型除細動器の作動に影響 を与える場合があります。


白宅療養など医療機関の外で、植込 み型心臓ペースメーカおよび植込み 型除細動器以外の医用電気機器を使 用される場合には、電波による影響 について個別に医用電気機器メーカ などに確認してください。




電波により医用電気機器の作動に影響 を与える場合があります。

医療機関などでは、以下を守ってく ださい。本機の雷波により医用雷気 機器に影響を及ぼす恐れがあります。







●医療機関が個々に使用禁止、持ち込み 禁止などの場所を定めている場合は、 その医療機関の指示に従ってくださ 1,1



指示

満員電車などの混雑した場所にいる ときは、本機の雷源を切ってくださ い。付近に植込み型心臓ペースメー カおよび植込み型除細動器を装着さ れている方がいる可能性があります。 電源が自動的に入る設定(アラーム 機能など) をしている場合は、設定を 解除してから電源を切ってください。 雷波により、植込み型心臓ペースメーカ および植込み型除細動器が誤動作する などの影響を与える場合があります。

お願いとご注意

ご利用にあたって

- ●事故や故障などにより本体/メモリカードに登録したデータ(電話帳・画像・サウンドなど)や設定した内容が消失・変化した場合の損害につきましては、当社は責任を負いかねますのであらかじめご了承ください。大切な電話帳などのデータは、控えをとっておかれることをおすめします。
- ・本機は、電波を利用しているため、特に屋内や地下街、トンネル内などでは電波が届きにくくなり、通話やデジタルテレビ視聴が困難になることがあります。また、通話・デジタルテレビ視聴中に電波状態の悪い場所へ移動すると、通話やデジタルテレビ映像が急に途切れることがありますので、あらかじめで了承ください。
- 本機を公共の場所でご利用いただくときは、周囲の 人たちの迷惑にならないようにご注意ください。
- ◆本機は電波法に定められた無線局です。したがって、電波法に基づく検査を受けていただくことがあります。あらかじめご了承ください。
- 一般の電話機やテレビ、ラジオなどをお使いになっている近くで本機を使用すると、雑音が入るなどの影響を与えることがありますので、ご注意ください。
- メモリカード(市販)をご利用になるときは、あらかじめメモリカードの取扱説明書をよくお読みになり、安全に正しくご使用ください。

●傍受(ぼうじゅ)にご注意ください。

本機は、デジタル信号を利用した傍受されにくい 商品ですが、電波を利用している関係上、通常の手 段を超える方法をとられたときには第三者が故意 に傍受するケースもまったくないとはいえませ ん。この点をご理解いただいたうえで、ご使用くだ さい。

- ■傍受とは、無線連絡の内容を第三者が別の受信機で放意または偶然に受信することです。
- 本機を他人に使わせたり譲渡する目的で海外へ持ち出す場合は、輸出許可が必要になることがありますが、旅行や出張時に本人が使用する目的で日本から持ち出し持ち帰る場合には許可は不要です。
 米国輸出規制により本機をキューバ、イラン、朝鮮民主主義人民共和国、スーダン、シリアへ持ち込むためには米国政府の輸出許可が必要です。

お取り扱いについて

- ◆本機は防水仕様ではありません。水に濡らしたり、 湿度の高い場所に置かないでください。
- ■雨の日にバッグの外のポケットに入れたり、手 に持って歩かないでください。
- ■エアコンの吹き出し口に置かないでください。 急激な温度変化により結露し、内部が腐食する 原因となります。
- ■洗面所などでは衣服に入れないでください。ポケットなどに入れて、身体をかがめたりすると、洗面所に落としたり、水で濡らす原因となります。
- 海辺などに持ち出すときは、海水がかかったり 直射日光があたらないように、バッグなどに入 れてください。
- ■汗をかいた手で触ったり、汗をかいた衣服のポケットに入れないでください。手や身体の汗が 本機の内部に浸透し、故障の原因となることが あります。
- ◆本機の電池パックを長い間外していたり、電池残量のない状態で放置したりすると、お客様が登録・設定した内容が消失または変化してしまうことがありますので、ご注意ください。なお、これらに関しまして発生した損害につきましては、当社は責任を負いかねますので、あらかじめで了承ください。
- 本機は温度:5℃~35℃、湿度:35%~85%の範囲でご使用ください。
- 極端な高温や低温環境、直射日光のあたる場所でので使用、保管は避けてください。
- ●カメラ部分に、直射日光が長時間あたると、内部の カラーフィルターが変色して、画像が変色することがあります。

- ●端子が汚れていると接触が悪くなり、充電不十分の原因となりますので、汚れたときは、端子を乾いた布、綿棒などでふいてください。
- お手入れは、乾いた柔らかい布などでふいてください。また、アルコール、シンナー、ペンジンなどを用いると色があせたり、文字が薄くなったりすることがありますので、ご使用にならないでください。
- 本機のディスプレイを堅い物でこすったり、傷つけないようご注意ください。
- ●無理な力がかからないようにお取り扱いください。故障やけがの原因となります。
- ■ズボンやスカートのポケットに入れたまま、しゃがみこんだり椅子などに座らないでください。特に厚い生地の衣服のときはご注意ください。
- ■カバンなどに入れるときは、重たい物の下にならないように十分ご注意ください。
- ◆イヤホンマイク端子に指定品以外のものは、取り付けないでください。誤動作を起こしたり、破損することがあります。
- ●電池パックを取り外すときは、必ず電源を切ってから取り外してください。 データの登録やメールの送信等の動作中に電池パックを取り外さないでください。データの消失・変化・破損などの恐れがあります。
- メモリカードの使用中は、メモリカードを取り外したり、本機の電源を切ったりしないでください。 データの消失・故障の原因となります。
- ●歩行中は、周囲の音が聞こえなくなるほど、音量を 上げないでください。事故の原因となります。
- 卓上ホルダー(オブション品)は自動車内で使用しないでください。振動により、故障の原因となります。

機能制限について

本機を機種変更/解約したり、長期間使用しなかったときは、次の機能が利用できなくなります。

カメラ、メディアプレイヤー、S!アプリ、テレビ

モバイルカメラについて

- ●カメラ機能は、一般的なモラルを守ってご使用ください。
- ◆大切なシーンを撮影されるときは、必ず試し撮りを行い、画像を表示して正しく撮影されていることをご確認ください。
- 撮影が禁止されている場所では撮影しないでください。

著作権等について

当像権について

●他人から無断で写真を撮られたり、撮られた写真 を無断で公表されたり、利用されたりすることが ないように主張できる権利が肖像権です。肖像権 には、誰にでも認められている人格権と、タレント など経済的利益に着目した財産権(パブリシティ 権)があります。したがって、勝手に他人やタレン トの写真を撮って公開したり、配布したりするこ とは違法行為となりますので、適切なカメラ機能 のご使用を心がけてください。

著作権について

●音楽、映像、コンピュータ・プログラム、データベー スなどは著作権法により、その著作物および著作 権者の権利が保護されています。こうした著作物 を複製することは、個人的にまたは家庭内で使用 する目的でのみ行うことができます。この目的を おえて、権利者の了解なくこれを複製(データ形式) の変換を含む)、改変、複製物の譲渡、ネットワーク 上での配信などを行うと、「著作権侵害」「著作者人 格権侵害」として損害賠償の請求や刑事処罰を受 けることがあります。本製品を使用して複製など をなされる場合には、著作権法を遵守のうえ、適切 なご使用を心がけていただきますよう、お願いい たします。また、本製品にはカメラ機能が搭載され ていますが、本力メラ機能を使用して記録したも のにつきましても、上記と同様の適切なご使用を 心がけていただきますよう、お願いいたします。

本機に搭載のソフトウェアは著作物であり、著作 権、著作者人格権などをはじめとする著作者等の 権利が含まれており、これらの権利は著作権法に より保護されています。ソフトウェアの全部また は一部を複製、修正あるいは改変したり、ハード ウェアから分離したり、逆アセンブル、逆コンパ イル、リバースエンジニアリング等は行わないで ください。第三者にこのような行為をさせること も同様です。

動画の撮影/再生の技術には「MPEG-4」が使われ ています。

This product is licensed under the MPEG-4 Visual Patent Portfolio License for the personal and non-commercial use of a consumer to (i) encode video in compliance with the MPEG-4 Video Standard ("MPEG-4 Video") and/or (ii) decode MPEG-4 Video that was encoded by a consumer engaged in a personal and noncommercial activity and/or was obtained from a licensed video provider. No license is granted or implied for any other use.

Additional information may be obtained from MPFGIA

See http://www.mpegla.com.

This product is licensed under the MPEG-4 Systems Patent Portfolio License for encoding in compliance with the MPEG-4 Systems Standard, except that an additional license and payment of royalties are necessary for encoding in connection with (i) data stored or replicated in physical media which is paid for on a title by title basis and/or (ii) data which is paid for on a title by title basis and is transmitted to an end user for permanent storage and/or use. Such additional license may be obtained from MPEG LA, LLC. See http://www.mpegla.com for additional

details

RSΛ

本機は、RSA Security Inc.のRSA® BSAFETMソフトウェアを搭載していま

RSAはRSA Security Inc. の登録商標で す。BSAFEはRSA Security Inc.の米国 およびその他の国における登録商標です。

この製品では、株式会社アプリックスがJava™アプリックスをJava™アプリケーションの実行速度が速くなるように設計したJBlend™が搭載されています。



Powered by JBlend™.

Copyright 1997-2009 Aplix Corporation.

All rights reserved.

JBlendおよびJBlendに関連する商標は、日本および その他の国における株式会社アプリックスの商標ま たは登録商標です。

JavaおよびJavaに関連する商標は、米国およびその他の国における米国Sun Microsystems, Inc.の商標または登録商標です。

Mich William

microSDHC™、microSD™、miniSD™はSD Card Associationの商標です。

NetFront®

本製品はインターネットブラウザおよびSMILブレーヤとして、株式会社ACCESSのNetFront BrowserおよびNetFront SMIL Playerを搭載しています。 Copyright® 2009 ACCESS CO., LTD. ACCESS、NetFrontは株式会社ACCESSの日本またはその他の国における商標または登録商標です。本製品の一部分にIndependent JPEG Groupが開発したモジュールが含まれています。

IrSimple™、IrSS™およびIrSimpleShot™は、Infrared Data Association®の商標です。

Bluetooth® is a trademark of the Bluetooth SIG. Inc.

Bluetooth°

The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Sharp is under license. Other trademarks and trade names are those of their respective owners.

Bluetooth®は、米国Bluetooth SIG,Inc.の登録商標です。

本機のBluetooth®機能の周波数帯では、電子レンジなどの産業・科学・医療用機器や、工場の製造ライン等で使用されている構内無線局、アマチュア無線局など(以下、「他の無線局」と略すが運用されています。他の無線機器との電波干渉を防止するため、下記の事項に注意してご使用ください。

- 1 Bluetooth®機能を使用する前に、近くで同じ周波 数帯を使用する「他の無線局」が運用されていな いことを目視で確認してください。
- 2 万一、Bluetooth[®]機能の使用にあたり、本機と「他 の無線局」との間に電波干渉の事例が発生した場 合には、速やかに使用場所を変えるか、Bluetooth[®] 機能の使用を停止(電波の発射を停止)してくだ さい。
- 3 その他不明な点やお困りのことが起きたときには、次の連絡先へお問い合わせください。

連絡先: ソフトバンクモバイルお客さまセンター ソフトバンク携帯電話から 157 (無料) (一般電話からおかけの場合、「お問い合わ せ先! (で写で15-42) を参照してください。)

この無線機器は、2.4GHz帯を使用します。変調方式としてFH-SS変調方式を採用し、与干渉距離は10m以下です。

2.4FH1

Microsoft、PowerPoint、Excelは、米国Microsoft Corporationの米国及びその他の国における登録商標です。

Powered by MascotCapsule®

Powered by MascotCapsule®/3DView package™ MascotCapsule® is a registered trademark of HI CORPORATION

©2002-2009 HI CORPORATION. All Rights Reserved.

FeliCaはソニー株式会社が開発した非接触ICカードの技術方式です。

FeliCaはソニー株式会社の登録商標です。 **②**は、フェリカネットワークス株式会社の登録商標です。

FeliCa is a contactless IC card technology developed by Sony Corporation. FeliCa is a trademark of Sony Corporation.

「おサイフケータイ」は、株式会社NTTドコモの登録商標です。

QRコードは株式会社デンソーウェーブの登録商標です。



本製品はAdobe Systems IncorporatedのAdobe® Flash® Lite™ テクノロジーを搭載しています。 Adobe Flash Lite Copyright © 2003-2007 Adobe Systems Incorporated. All rights

reserved.

Adobe、Flash、およびFlash Lite はAdobe Systems Incorporated(アドビシステムズ社)の米国ならびにその他の国における登録商標または商標です。

お目覚めTV、ベールビュー、VeilView、スマートリンク、 見せかけコール、スマートリサイズズーム、AQUOS、 AQUOS SHOT、 笑顔フォーカスシャッター、振り向き シャープ株式会社の登録商標または商標です。



ドキュメントビューアは、 Picsel Technologiesにより実現しています。

Picsel, Picsel Powered, Picsel Viewer, Picsel File Viewer, Picsel Document Viewer, Picsel PDF ViewerまたはPicselキューブロゴはPicsel Technologiesの商標または登録商標です。

着うた®、着うたフル®は、株式会社ソニー・ミュージックエンタテインメントの登録商標です。

BookSurfingは株式会社セルシス、株式会社ボイジャー、株式会社インフォシティの登録商標です。

「ジーニアスモバイル英和辞典」©2005-2008 Taishukan 「ジーニアスモバイル和英辞典」©2005-2008 Taishukan 「明鏡モバイル国語辞典」©2005-2008 Taishukan

- ●「ジーニアス英和辞典MX.net」 ©KONISHI Tomoshichi, MINAMIDE Kosei & Taishukan. 2008
- ●「ジーニアス和英辞典MX.net」 ®KONISHI Tomoshichi, MINAMIDE Kosei & Taishukan, 2008
- ●「明鏡国語辞典MX.net |

©KITAHARA Yasuo & Taishukan, 2008

- 「イミダス百科」◎集英社
- ●「日本大百科全書(ニッポニカ)」「デジタル大辞泉」 「プログレッシブ英和中辞典」 「プログレッシブ和英中辞典」◎小学館
- ●「Amazon.co.jp」は、Amazon.com, Inc.または その関連会社の商標です。



EUPHONY™は、DiMAGIC (ダイマジック社)の仮想音源処理技術を含む総合的な音質向上技術の商標です。



ダイナミックレンジ補正は、Apical Limited のiridixテクノロジーを使用しています。

apical

「**らくらく瞬漢ルーペTM**」は株式会社アイエスピーの商標です。

PhotoSolid[®]、FaceSolid[®]、MovieSolid[®]、Frame Solid[®]、PhotoScouter[®]、TrackSolid[™]、Strobo Photo[™]は株式会社モルフォの登録商標または商標 です。

SOFTBANK およびソフトバンクの名称、ロゴは日本 国およびその他の国におけるソフトバンク株式会社 の登録商標または商標です。

「Yahoo!」および「Yahoo!」「Y!」のロゴマークは、 米国Yahoo! Inc.の登録商標または商標です。

CP8 PATENT

S!アプリ、S! GPSナビ、モバイルウィジェット、S!速報ニュース、S!情報チャンネル、S!ともだち状況、S!ー斉トーク、ちかチャット、S!電話帳パックアップ、お天気アイコン、ダブルナンバ・、きせかえアレンジ、TVコール、生活アプリ、インブットメモリ、着デコ、PCメール、PCサイトブラウザ、マルチジョブ、デコレメール、S!メール、フィーリングメール、位置ナビ、スカイメール、写メール、ムービー写メール、安心遠隔ロック、コンテンツ得パック、S-1バトルはソフトバンクモバイル株式会社の登録商標または商標です。

その他の記載している会社名、製品名は各社の登録商標または商標です。

携帯電話機の比吸収率(SAR)について

この機種【933SH】の携帯電話機は、国が定めた電波の人体吸収に関する技術基準に適合しています。

この技術基準は、人体頭部のそばで使用する携帯電話機などの無線機器から送せされる電波が人間の健康し影響を及ぼさないよう、科学的根拠に基づいて定められたものであり、人体頭部に吸収さいる電波のデリエネルギー量を表す比較い、率(SAR: Specific Absorption Rate)について、これが2 W/kg※の許容値をは、使用者の年齢や身体の大きさに関係なく十分な安全率を含んでおり、世界保健機関(WMO)と協力関係にある国際非電離放射線防護委員会(ICNIRP)が示した国際的なガイドラインと同じ値になっています。

すべての機種の携帯電話機は、発売開 始前に、電波法に基づき国の技術基準に 適合していることの証明(技術基準適合 証明)を受ける必要があります。この携 帯電話機【933SH】も財団法人テレコ ムエンジニアリングセンターから技術基 準適合証明を受けており、SARは0.574 W/kgです。この値は、技術基準適合証 明のために財団法人テレコムエンジニア リングセンターによって取得されたもの であり、国が定めた方法に従い、携帯電 話機の送信電力を最大にして測定された 最大の値です。個々の製品によって SAR に多少の差異が生じることもあります が、いずれも許容値を満足しています。 また、携帯電話機は、携帯電話基地局と の通信に必要な最低限の送信電力になる よう設計されているため、実際に通話し ている状態では、通常 SARはより小さ い値となります。

SARについて、さらに詳しい情報をお知りになりたい方は、下記のホームページをご参照ください。

総務省のホームページ http://www.tele.soumu.go.jp/j/ele/ index htm

社団法人電波産業会のホームページ http://www.arib-emf.org/initiation/ sar.html

※技術基準については、電波法関連省 令(無線設備規則第14条の2)で規 定されています。

「ソフトバンクのボディ SARポリシー」に ついて

*ボディ(身体) SARとは:携帯電話機本体を身体に装着した状態で、携帯電話機にイヤホンマイク等を装着して連続通 機にイヤホンマイク等を装着して連続通 1話をした場合の最大送信電力時での比吸 収率(SAR)のことです。

**比吸収率(SAR): 6分間連続通話状態で測定した値を掲載しています。当社では、ボディSARに関する技術基準として、米国連邦通信委員会(FCC)の 基準および欧州に対ける情報を掲載しています。詳細は「米国連邦通信委員会(FCC)の電波ばく霧の影響に関する情報。 報」「欧州における電波ばく露の影響に関する情報」「欧州における電波ばく露の影響に関する情報」をご参照ください。

***身体装着の場合:一般的な携帯電話の装着法として身体から1.5センチに 距離を保う携帯電話機の背面を身体に向ける位置で測定試験を実施しています。 電波ばく露要件を満たすためには、身間で で30世紀である。 地末る装身具を使用し、ベルトクリップ いないもいのを選んでください。

ソフトバンクモバイルホームページから も内容をご確認いただけます。 http://www.softbankmobile.co.jp/ ja/info/public/emf/emf02.html 「米国連邦通信委員会 (FCC) の電波ばく露の影響に関する情報!

米国連邦通信委員会の指針は、独立した 科学機関が定期的かつ周到に科学的研究 を行った結果策定された基準に基づいて います。この許容値は、使用者の年齢や 健康状態にかかわらず十分に安全な値と なっています。

携帯電話機から送出される電波の人体に 対する影響は、比吸収率(SAR: Specific Absorption Rate)という単位を用いて 測定します。FCCで定められているSAR の許容値は、1.6W/kgとなっています。 測定試験は機種でとにFCCが定めた基準 で実施され、下配のとおり本取扱説明書 の記載に従って身体に装着した場合は 0.527W/kgです。

身体装着の場合:この携帯電話機 (19335H)では、一般的な携帯電話の装 蓋法として身体から1.5 センチに距離を 保ち携帯電話機の背面を身体に向ける位 置で測定試験を実施しています。FCCの 電がはく露要件を満たすためには、身体 から1.5 センチの距離に携帯電話を固定 出来る装身具を使用し、ベルトクリップ いないものを選んでください。

上記の条件に該当しない装身具は、FCC の電波ばく露要件を満たさない場合もあるので使用を避けてください。 比吸収率 (SAR) に関するさらに詳しい 情報をお知りになりたい方は下記のホー

ムページを参照してください。

Cellular Telecommunications & Internet Association (CTIA) のホーム ページ

http://www.phonefacts.net (英文の

「欧州における電波ばく露の影響に関する情報」

この携帯電話機 [9335H] は無線送受信機器です。本品は国際指針の推奨する電波の許容値を超えないことを確認しています。この指針は、独立した科学機関である国際非電離放射線防護委員会(ICNIRP) が策定したものであら、その許容値は、使用者の年齢や健康状態にかからず十分に安全な値となっています。携帯電話機から送出される電波の人体に対する影響は、比吸収率(SAR: Specific Absorption Rate)という単位を用いて測定します。携帯機器におけるSAR計容値は2 2W/kgで、身体に装着した場合のSARの最高値は0.563W/kg*で写

SAR測定の際には、送信電力を最大にし て測定するため、実際に通話している状 態では、通常SARはより小さい値となり ます。これは、携帯電話機は、通信に必 要な最低限の送信電力で基地局との通信 を行うように設計されているためです。 世界保健機関は、モバイル機器の使用に 関して、現在の科学情報では人体への悪 影響は確認されていないと表明していま す。また、電波の影響を抑えたい場合に は、通話時間を短くすること、または携 帯電話機を頭部や身体から離して使用す ることが出来るハンズフリー用機器の利 用を推奨しています。さらに詳しい情報 をお知りになりたい場合には世界保健機 関のホームページをご参照ください。 (http://www.who.int/emf) (英文の

*身体に装着した場合の測定試験は FCCが定めた基準に従って実施されています。値は欧州の条件に基づいたものです。

Safety Precautions

Read safety precautions before using handset.


- Observe precautions to avoid injury to self or others, or damage to property.
- SoftBank is not liable for any damages resulting from use of this product.

These labels indicate the degree of risk from improper use. Make sure you thoroughly understand their meanings before reading on.

⚠ DANGER	Great risk of death or serious injury from improper use
⚠ WARNING	Risk of death or serious injury from improper use
⚠ CAUTION	Risk of serious injury or damage to property from improper use

These symbols indicate prohibited or compulsory actions. Make sure you thoroughly understand their meanings before reading on.





Handset, Battery, USIM Card, Charger (Sold Separately) & Memory Card (Sold Separately)



Use specified battery, Charger (sold separately) and Desktop Holder (sold separately) only.



Non-specified equipment use may cause battery to leak, overheat, burst or ignite, and may cause Charger to overheat, ignite, malfunction, etc.

Do not disassemble, modify or solder handset or related hardware. May cause fire, injury, electric shock or



Do Not Disassemble

overheat, burst or ignite. Modifying handsets is prohibited by the Radio Law and subject to a penalty.

Do not expose handset or related hardware to liquids.

malfunction. Battery may leak,



Do not leave handset or related hardware wet after exposure to water. pet urine, etc., and do not charge wet battery. May cause overheating, electric shock, fire, injury or malfunction. Use them in an appropriate place properly.

Do not charge battery in or expose handset or related hardware to extreme heat (e.g., near fire or sources of heat, in direct sunlight. inside vehicles, etc.).



May cause warping/malfunction: battery may leak, overheat, ignite or burst. Handset or related hardware may become hot to the touch, leading to burn injuries, etc.


Do not force battery/Charger into handset. Check the direction and retrv.



Battery may leak, overheat, burst, ianite, etc.



⚠ WARNING





ignite. Handset/Charger may overheat, emit smoke, ignite, malfunction, etc.

Keep handset off and Charger disconnected near gas stations or places with fire/explosion risk.



Handset use near petrochemicals or other flammables may cause fire/ explosion: turn handset off before using Osaifu-Keitai® at gas stations (cancel IC Card Lock beforehand).

Do not apply strong shocks or impacts.



Do not drop/throw handset or related hardware. Battery may leak, overheat. burst or ignite, resulting in fire, electric shock, malfunction, etc.

Prohibited

If there is unusual sound/odor. smoke or any other abnormality:



Continued use may cause fire, electric shock, etc.; grasp plug to disconnect Charger, turn off handset, then remove battery, being careful not to burn or iniure vourself.

Keep liquids (water, pet urine, etc.) or conductive material (pencil lead, metallic strip, metal jewelry, etc.) away from charging terminals.

Prohibited **External Device Port or Memory**

May cause short circuit, resulting in fire, malfunction, etc.

Card Slot.

↑ CAUTION

Do not place handset or related hardware on unstable surfaces.



Handset or related hardware may fall. resulting in injury, malfunction, etc.; be especially careful when Vibration is set or while charging.

Prohibited

Keep handset and related hardware out of infants' reach.



Infants may choke from swallowing handset or related hardware or be iniured, etc.

If your child is using handset and related hardware, explain all instructions and supervise usage. Misuse may cause injury, etc.





Battery

ignite, etc.

DANGER

Read battery label to confirm battery type: use/dispose of battery accordingly.

Symbol on Label	Battery Type	
Li-ion00	Lithium-ion	

Do not dispose of battery in fire. Battery may leak, burst, ignite, etc.



Prohibited

Do not damage battery (with a nail, hammer, foot, etc.) or subject it to strong impacts or shocks. Battery may leak, overheat, burst,



Prohibited

Keep wire or other metal objects away from battery terminals. Do not carry/store battery with conductive material (pencil lead. metallic strip, metal iewelry, etc.).



Battery may leak, overheat, burst, ianite, etc.

If battery fluid gets in eyes, do not rub: rinse with water and consult a doctor immediately. Eves may be severely damaged.



Compulsory

⚠ WARNING

If battery fluid contacts skin or clothes, discontinue handset use and rinse with clean water immediately.



May cause skin damage.

If battery does not charge properly, stop trying.



Battery may leak, overheat, burst, ignite, etc.

Compulsory

If there is abnormal odor, excessive heat, discoloration or distortion. remove battery, being careful not to burn or injure yourself. Avoid fire sources.



Continued use may cause battery to leak, overheat, burst, ignite, etc.

Keep battery out of pets' reach. If bitten, battery may leak, overheat, burst, ignite, etc.



⚠ CAUTION

Do not dispose of an exhausted battery with ordinary refuse.

Tape over battery terminals before disposal. Take battery to a SoftBank Shop, or follow the local disposal regulations.



Handset

⚠ WARNING

Do not use Mobile Light near people's faces.


Evesight may be temporarily affected leading to accidents. CAUTION:



Use of controls, adjustments or performance of procedure other than those specified herein may result

CLASS 1 LED Product

in hazardous radiation exposure. As the emission level from Mobile Light LED used in this product is harmful to the eyes, do not attempt to disassemble the cabinet. Servicing is limited to qualified servicing station only.



■Mobile Light LED Properties


- a) Emission Duration: Continuous
- b) Wavelength White: 400 - 700 nm
- c) Maximum Emission Output

White: 840 µW (4.8 mW inside handset)

beforehand

Do not use handset while driving or cvclina.

Accidents may result.







Turn handset power off near electronic devices that employ high precision control systems or weak signals.



May cause electronic malfunctions, etc. Be especially careful near the following devices:

Hearing aids, implanted pacemakers/ defibrillators and other electronic medical equipment: fire alarms. automatic doors and other automatic control devices

Turn handset power off before boarding aircraft to avoid effects of radio waves on aircraft operation.



If mobile phone use is allowed on board, use handset properly by following airline rules or cabin crew's directions.

Users with a heart condition should

adjust ringtone Vibration and Volume as needed.

May cause heart damage.

If thunder is heard while outdoors. turn power off: find cover.

There is a risk of lightning strike or electric shock




Compulsory

Do not look into Infrared Port during infrared transmissions. Evesight may be affected.



Confirm there is ample space for Motion Control use: hold handset firmly and shake it gently.







Prohibited

Compulsory

⚠ CAUTION

Do not use handset when it may affect a vehicle's electronic equipment.





Metal and other materials may cause skin irritation, rashes, or itchiness depending on your physical condition.

Keep handset away from magnetic cards, etc.

Data on bank cards, credit cards, telephone cards, floppy disks, etc. may be lost.

Do not swing handset by strap.

May harm self or others; strap may break, resulting in injury or handset malfunction/breakage.



Prohibited

Handset may become hot while in use, especially at high temperature. Prolonged contact with skin may cause

burn injuries.



Always maintain some distance from Speaker while ringtones. music or other handset sounds play. Excessive volume may damage ears or hearing.



Keep fingers, straps, etc. outside when opening/closing handset. May cause injury, breakage, etc.



Watch TV from a distance in good liaht.





Moderate handset volume when using Headphones.




Excessive volume may damage ears or hearing.



Charger (Sold Separately)

↑ WARNING

Do not cover/wrap Charger while charging.





Prohibited

Prohibited

Disconnect


Power Source

Compulsory

Power Source

Use only the specified voltage.

Non-specified voltages may cause fire. malfunction, etc.




• In-Car Charger (sold separately; use in negative earth vehicles only): DC 12V/24V Input

Do not use power adapters. Using Charger with step-up/step-down transformer may cause fire, electric shock or malfunction

Leave Charger unplugged during periods of disuse; grasp plug to disconnect it.

May cause electric shock, fire or malfunction




Non-specified fuse may cause fire or malfunction. See In-Car Charger manual for details.


If liquids (water, pet urine, etc.) seep inside Charger, grasp plug and disconnect it immediately.

May cause electric shock, smoke or fire.

If plug is dusty, grasp it and disconnect Charger, then clean with a dry cloth.

Fire may result.





earth vehicles only.

Plug Charger firmly into the outlet. keeping the plug and Charger/ **Desktop Holder charging terminals** away from conductive material (pencil lead, metallic strip, metal iewelry, etc.).

May cause electric shock, short circuit, fire, etc.

Do not touch Charger plug with wet hands.

May cause electric shock, malfunction, etc.

Do not touch Charger if thunder is heard.

May cause electric shock, etc.



Do Not Use

Wet Hands

Prohibited

Compulsory

Prohibited

Compulsory

before cleaning. May cause electric shock, etc.



Disconnect Power Source

Always grasp plug (not cord) to disconnect Charger.

Pulling the plug by cord may damage cord, causing electric shock, fire, etc.

Grasp plug and disconnect Charger

⚠ CAUTION



Do not subject AC Charger (sold separately) to strong shocks or impacts while it is plugged into the outlet.



May cause malfunction or injury.

Do not touch charging terminals of Desktop Holder (sold separately) while it is connected to the outlet. May cause burn injuries.



Handset Use & Electronic Medical Equipment

This section is based on "Guidelines on the Use of Radio Communications Equipment such as Cellular Telephones and Safeguards for Electronic Medical Equipment" (Electromagnetic Compatibility Conference, April 1997) and "Report of Investigation of the Effects of Radio Waves on Medical Equipment, etc." (Association of Radio Industries and Businesses, March 2001).

⚠ WARNING

Persons with implanted pacemaker/ defibrillator should keep handset more than 22 cm away.



Radio waves may interfere with implanted pacemakers or defibrillators.

If you intend to use electronic medical equipment other than implanted pacemaker/defibrillator outside medical facilities, consult the vendor on radio wave effects. Radio waves may interfere with

electronic medical equipment.



Compulsory

Observe these rules inside medical facilities to avoid effects of radio waves on electronic medical equipment:



- Keep handset off in hospitals; cancel the setting that turns handset power on automatically (alarm, etc.) heforehand
- Even in lobbies or other places where handset use is permitted, keep handset off near electronic medical equipment.
- Obey medical facility rules on mobile phone use.

Turn handset off in crowds or trains where persons with implanted pacemaker/defibrillator may be near; cancel the setting that turns handset power on automatically (alarm, etc.) beforehand.



Radio waves may interfere with implanted pacemakers or defibrillators causing such devices to malfunction.





General Notes

General Use

- SoftBank is not liable for any damages resulting from accidental loss/alteration of files saved on handset/Memory Card. Keep separate copies of Phone Book entries, etc.
- Handset transmissions/TV signal reception may be disrupted inside buildings, tunnels or underground, or when moving into/out of such places.
- Use handset without disturbing others.
- Handsets are radios as stipulated by the Radio Law. Under the Radio Law, handsets must be submitted for inspection upon request.
- Handset use near landlines, TVs or radios may cause interference.
- For proper use of Memory Card (sold separately), read the manual beforehand.
- Beware of eavesdropping.
 Because this service is completely digital, the possibility of signal interception is greatly reduced. However, some transmissions may be overheard

Eavesdropping

Deliberate/accidental interception of communications constitutes eavesdropping.

• An export license may be required to carry the handset into other countries if it is to be used by or transferred to another person. However, no such license is required when you take the handset abroad for personal use on a vacation or business trip and then bring it back. Export control regulations in the United States provide that an export license granted by the US government is required to carry the handset into Cuba, Iran, North Korea, Sudan or Syria.

Handset & Hardware Care

- Handset is not water-proof. Avoid exposure to liquids and high humidity.
- Keep handset away from precipitation.
 Cold air from air conditioning, etc. may
- condense causing corrosion.

 Avoid dropping handset in damp places (restroom, bath/shower room, etc.).
- On the beach, keep handset away from water and direct sunlight.
- Perspiration may seep inside handset causing malfunction.
- If handset is left with no battery or an exhausted one, data may be altered/lost. SoftBank is not liable for any resulting damages.
- Use handset between 5℃ 35℃ (35% 85% humidity).
- Avoid extreme temperatures and direct sunlight.
- Exposing lens to direct sunlight may damage color filter and affect image color.
- Battery may not charge properly if ports/ terminals are obstructed by dust, etc. Clean with a dry cloth, cotton swab, etc.
- Clean handset with a dry, soft cloth. Using alcohol, thinner, etc. may damage it.
- Avoid scratching handset Display.
- Avoid heavy objects or excessive pressure.
 May cause malfunction or injury.
- Do not sit on handset in back pants pocket.
- Do not place heavy objects on handset inside handbags, packs, etc.

- Connect only specified products to Headphone Port. Other devices may malfunction or cause damage.
- Always turn off handset before removing battery. If battery is removed while saving data or sending mail, data may be lost, changed or destroyed.
- Do not remove Memory Card or turn off handset power while using the card; may result in data loss or malfunction.
- When walking outside, moderate handset volume to avoid accidents.
- Do not use Desktop Holder (sold separately) inside vehicles. Vibration may damage handset. etc.

Function Usage Limits

These functions are disabled after handset upgrade/replacement or service cancellation: Camera; Media Player; S! Applications; TV. After a period of disuse, these functions may be unusable; retrieve Network Information to restore usability.

Mobile Camera

- Mind your manners when using handset camera.
- Test the camera before capturing/recording special moments.
- Do not use handset camera in places where photography or videography is prohibited.



Portrait Rights

Portrait rights protect individuals' right to refuse to be photographed or to refuse unauthorized publication/use of their photographs. Portrait rights consist of the right to privacy, which is applicable to all persons, and the right to publicity, which protects the interests of celebrities. Therefore, photographing others including celebrities and publicizing/distributing their photographs without permission is illegal; use handset camera responsively.

Copyrights

Copyright laws protect sounds, images, computer programs, databases, other materials and copyright holders. Duplicated material is limited to private use only. Use of materials beyond this limit or without permission of copyright holders may constitute copyright infringement, and be subject to criminal punishment. Comply with copyright laws when using images captured with handset camera.

Electromagnetic Waves

For body-worn operation, this phone has been tested and meets RF exposure guidelines when used with accessories containing no metal, that position handset a minimum of 15 mm from the body. Use of other accessories may not ensure compliance with RF exposure guidelines.

CE Declaration of Conformity

C € 0168

Hereby, Sharp Telecommunications of Europe Ltd, declares that 933SH is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. A copy of the original declaration of conformity for each model can be found at the following Internet address: http://www.sharp.co.jpik-tai/

Battery - CAUTION

Use specified battery or Charger only. Non-specified equipment use may cause malfunctions, electric shock or fire due to battery leakage, overheating or bursting.

Do not dispose of an exhausted battery with ordinary refuse; always tape over battery terminals before disposal. Take battery to a SoftBank Shop, or follow the local disposal regulations.

Charge battery in ambient temperatures between 5℃ and 35℃; outside this range, battery may leak/overheat and performance may deteriorate.

European RF Exposure Information

Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves recommended by international guidelines. These guidelines were developed by the independent scientific organization ICNIRP and include safety margins designed to assure the protection of all persons, regardless of age and health.

The guidelines use a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit for mobile devices is 2 W/kg. As mobile devices offer a range of functions, they can be used in other positions, such as on the body as described in this user guide*. Highest SAR value:

Model	At the Ear**	On the Body
933SH	0.616 W/kg	0.563 W/kg

As SAR is measured utilizing the device's highest transmitting power the actual SAR of this device while operating is typically below that indicated above. This is due to automatic changes to the power level of the device to ensure it only uses the minimum level required to reach the Network.

The World Health Organization has stated that present scientific information does not indicate the need for any special precautions for the use of mobile devices. They note that if you want to reduce your exposure then you can do so by limiting the length of calls or using a handsfree device to keep the mobile phone away from the head and body.



^{*}Please see Electromagnetic Waves on the left for important notes regarding body-worn operation.

^{**}Measured in accordance with international guidelines for testing.

FCC Notice

- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
- (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

FCC Information to User

This equipment has been tested and found to comply with the limits of a Class B digital device, pursuant to Part 15 of the ECC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no quarantee that interference will not occur in a particular installation: if this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- 1. Reorient/relocate the receiving antenna.
- 2. Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- 4. Consult the dealer or an experienced radio/

FCC RF Exposure Information

Your handset is a radio transmitter and receiver.

It is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government.

The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health.

The exposure standard for wireless handsets employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6 W/kg. Highest SAR value:

Model	FCC ID	At the Ear	On the Body
933SH	APYHRO00098	0.455 W/kg	0.527 W/kg

This device was tested for typical body-worn operations with the back of the handset kept 1.5 cm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 1.5 cm separation distance between the user's body and the back of the handset. The use of beltclips, holsters and similar accessories should not contain metallic components in its assembly.

The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided. The ECC has granted an Equipment Authorization for this model handset with all reported SAR levels evaluated as in compliance with the FCC RF emission guidelines. SAR information on this model handset is on file with the ECC and can be found at https://fiallfoss.fcc.gov/oetcf/eas/reports/ GenericSearch.cfm under the Display Grant section after searching on the corresponding FCC ID (see table on the left). Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications & Internet Association (CTIA) Website at http://www.phonefacts.net.

MEMO